
TempDot. Plus

Labels for cumulative rise time/temperature

Product Specifications

<u> </u>	
temperature accuracy	±1° C
time accuracy	± 15%Timeat isothermal conditions
chemical tracer	Blue chemical liquid encapsulatedin a blister, FoodChemical Code, FDA approved (Title 21), GRAS (Generally Recognized as Safe)
Label size	40mm L x 19mm H x 0.5 mm THK
thickness of plastic foam	about2.5 mm
Top foam model	Model51050,51051, 51052,51054, 51055,51056
activation method	Pushing with fingersabove ambient temperature threshold
use	Apply to clean, drysurfaces
Storage(when inactive)	Room temperature, cool, darkplace, away from direct heat and sunlight. Ideally at22°C, 20-80%RH
expiration date	transportation, shipping
packaging	501abelsper pack
moisture-proof	Splash resistant, not suitable for immersion inwater



TempDot™Pluslabels should he stored temperature and must be activated above the reaction temperature threshold. Activation is achieved by pressing with a finger. The word "On" appears active in the first windowdisplay. Within 5 minutes thereafter, apply the label to the product at or below reaction temperature. The blue dye melts and migrates at a controlled rate through a large white window. This indicates the cumulative time of exposure above the temperature threshold. thetemperature falls below a threshold, the dye solidifies and stops moving. The TempDot®Plus label provides immediate visual indication if the temperature exceeds a threshold.

- Each label has a serial number traceable
- Irreversible, single-use time/temperature indicator label
- Display accumulated temperature/hour of exposure above temperature threshold

DeltaTRAK manufactures products under ISO9000 quality management system

SS0126 13L1C



Shenzhen DTIInvestment Development Co., Ltd. Room 908, No. 6 Dongsha Road, Shuitousha Village, Nan'ao Town, Longgang District, Shenzhen City, China Sales: 86 (755) 8442-9007/8442-9388 Technical Support: 86 (755) 8442-9800 Ext. 805 Fax: 86 (755) 84429388 www.deltatrakchina.com.cn, www.deltatrak.com